



While installing, when you arrive at a corner, a squared off or angled gutter ending, place a strip of masking tape across the grate and mark with a pen or pencil to the required length and angle. If a fiberglass rod is in the path of the cut, pull PVC cap off 1 end with a pair of pliers and remove the rod. Using a circular saw with a fine-tooth blade (40 tooth minimum), begin to cut the grate along the line. Let the saw come to full speed before beginning to cut and cut slowly across the grate to reduce the risk of shattering the grate. Always wear safety glasses during this process to avoid eye damage. When finished, check for sharp edges and if found, slightly buff edge with a fine sandpaper then install grate.

Cleaning and Maintenance:

To keep the grating looking new, the grate must be kept free of debris. A mild detergent with water and a brush will keep stains from occurring.

Remember to regularly inspect the fasteners to ensure that the grate is properly secured to avoid any possible injuries.

TEMPLATE REQUIREMENTS

All corners that are not a standard 45 or 90 degrees, will need to be fabricated by Daldorado, LLC. Please follow these guidelines when making your templates.

Templates must be made from plywood or masonry board. Cardboard is not permitted.

Templates must fit the same as the grating corner will fit.

Templates need to have clean cut lines, no jagged edges.

Templates must be marked with the following information: the number of the corner, top side of template, pool location and the direction of the connector pins.

If more than one template is needed, a drawing of the pool must accompany the templates showing each templates location on the pool.

These requirements are necessary to ensure the highest quality product.

If you have any questions, please call any of our knowledgeable staff at 888-509-8128.